



Master Hook Instructions

The Master Hook is a purpose-engineered, uniquely shaped steel hook designed to fit securely over a ladder rung and around the stile. It provides a stable, hands-free hanging point for paint buckets, mixing pots, tool bags and accessories — keeping essential equipment within easy reach, reducing unnecessary climbing, and helping keep your workspace tidy and safe

NOTICE

**PLEASE READ THE SAFETY GUIDELINES
IN CONJUNCTION WITH THE PRODUCT INSTRUCTIONS**

FITTING INSTRUCTIONS Step-by-Step

- Prepare your ladder — Ensure the ladder is fully erected, locked open, and standing on firm, level ground. Confirm it is in good, safe working order before fitting the hook.
- Orient the hook — Hold the Master Hook so the stepped inner section faces in toward the ladder stile.
- Engage the rung — Place the inner loop over the top of your chosen ladder rung.
- Secure around the stile — Rotate the hook so the stepped section wraps around the rear of the ladder stile, sitting flush against it.
- Check security — Pull gently upward and outward. The hook should grip firmly with no wobble or slip. The curved outer end will extend sideways, ready to accept your load.
- Place your load — Rest your bucket, tool or item on the outer curved section. Centre the weight and check balance before releasing.

Maximum Safe Load: 10 kg / 22 lb

Always cross-reference with your ladder manufacturer's maximum permitted side-load guidelines.

- ✓ DO
- ✓ Fit only when the ladder is stable and fully secured
- ✓ Position at a height where you can reach comfortably without stretching or overreaching
- ✓ Keep all loads balanced and under 10 kg
- ✓ Ensure hanging items clear walls, the ground and obstacles so they do not catch or pull free
- ✓ Inspect the hook before every use — check for bends, cracks, wear, or damage to the end caps
- ✓ Remove the hook before moving, repositioning or storing the ladder
- ✓ Clean with warm soapy water; dry thoroughly after use to prevent corrosion
- ✓ Store flat or hanging in a dry place, away from heavy items that could distort the shape

- ✗ DON'T
- ✗ Never use as a foothold, step or to support any part of your body weight — for equipment only
- ✗ Do not exceed the 10 kg maximum load
- ✗ Do not use if the hook is bent, cracked, worn or damaged in any way
- ✗ Do not fit to loose, worn, damaged or visibly faulty ladder rungs or stiles
- ✗ Do not let items swing freely — sudden movement can dislodge the hook or destabilise the ladder
- ✗ Do not leave the hook attached while the ladder is being carried or repositioned
- ✗ Do not use on ladders with non-standard rungs/stiles where the fit is loose or insecure
- ✗ Do not hang unsealed, hot, corrosive or hazardous containers

SAFETY REMINDERS

Maintain three points of contact at all times when climbing or working on ladders
Never overreach — move and re-site the ladder instead
This product is a working convenience aid; it does not replace standard ladder safety training or safe working practices
Not intended for use by children
Keep away from open flames and extreme heat

PRODUCT SPECIFICATION

Name: ClimbSafe™ The Master Hook
Material: High-tensile formed steel with protective finish
Max Load: 10 kg
Designed & Manufactured in the UK

Disclaimer

These SAFETY GUIDELINES are not an exhaustive list of precautions.
They should not be taken as a substitute for any additional measures found necessary on site, nor do they guarantee that the use of a ladder is safe without regard to local conditions and are always subject to an employer's risk assessment.